



SECTION A-A

N= STEEL NUT

代號N請依目錄

PART NO.	N